



Fitting Instructions for PSH1002 and PSH1011

The Mackay High Pressure Power Steering Hoses to suit Ford 6Cyl (EF, EL, NF, NL, XH, DF, DL) features a Fixed O-Ring Flare fitting on the pump end of the hose, this replaces the common failure point of the OE Ford Swivel fitting.

When attaching the Mackay hose you must first remove the existing Ford Adaptor so that the Fixed O-ring Flare can be connected directly into the pump. **DO NOT!** re-use the Ford Adaptor that is designed for use with the Ford Swivel fitting.

The Mackay Power Steering Hose must be screwed directly into the pump.

Original Ford Hose
With Swivel Fitting



Remove Ford Adaptor



Fit Mackay Hose
Directly To Pump

