


MOTORSPORT MAP SENSOR 5 BAR MAP-501

RACEWORKS™
PASSION FOR PERFORMANCE

Raceworks recommended these sensors are not be mounted directly into the fuel rail or engine block; rather are remotely mounted and connected via a flexible hose. If required, use Pressure Sensor Extension Hose RWM-005.



CALIBRATION

0kpa Absolute = 0.5v
500kpa Absolute = 4.5v



SPECIFICATIONS


- Premium Compact Sensor with Stainless Steel Body
- 0-5 Volt, 1/8" NPT, Inc Plug & Pins



Looking into the back of the connector or sensor


WIRING DETAILS

PIN	Description
1	Sensor Ground
2	Signal
3	+5V



19mm Hex Head
1/8" NPT Thread

CONNECTOR KIT



Use tool RWT-005 to crimp the pins.

